

Colloidal dynamics in a glass forming solvent at low temperatures

Chiara Caronna^{1,2}, Yuriy Chushkin¹, Anders Madsen¹

¹European Synchrotron Radiation Facility, ²Department of Physical and Astronomical Sciences, University of Palermo

We have measured the dynamics of colloidal nano-particles in a glass forming solvent by means of X-ray photon correlation spectroscopy (XPCS). In order to follow the dynamics close to the temperature induced glass transition, we have used a mini cryostat allowing temperatures down to 80K with a very high stability (~ 0.01 K).

Our measurements have been performed on a dilute suspension of silica particles ($D=0.5$ micron) in propanediol, a liquid that goes through a glass transition at $T_g=170$ K. By using the Medipix detector, a 2-D pixelated detector with a full frame rate up to 30 Hz, it has been possible to quantify the dynamics in the temperature range 240K-205K.

Interestingly, though the solvent is still far from the glassy state, our data clearly show that the colloidal dynamics change around $T=215$ K (figure 1 and 2). At “high” temperatures the particle dynamics is Brownian, with a dispersion relation Γ proportional to Q^2 and simple exponential decay of the correlation functions. By decreasing the temperature, we obtain compressed exponential correlation functions ($\gamma > 1$) and simultaneously, a gradual change occurs in the power-law of the dispersion with an exponent approaching ~ 1 at $T=205$ K.

Measurements on suspensions with higher volume fraction suggest that the dynamics below ~ 215 K is collective and our results can be explained by a transition from continuous to intermittent dynamics, probably driven by stress relaxations of the solvent [1].




Figure 1 Dispersion relation at various temperatures. Lines are guide to the eye




Figure 2 Compressing exponent vs Q at various temperatures. Lines are guide to the eye